



Read STXM (NeXus)

Code supplied by Ben Watts (May2015)
First integrated into aXis2000 July 2015 - needs IDL 8.x



Example NeXus files read by aXis2000

1. uSample_Image_2015-04-16_003.hdf5 analog0
2. uSample_Line_2015-04-16_001.hdf5 analog0
3. uSample_Stack_2015-04-16_002.hdf5 analog0 - 1 image (550 eV)
4. uSample_Stack_2015-04-16_002.hdf5 analog0 - 1 image (600 eV)

